


1014 Ankerbojen Beleuchtung
1014 Anchor Buoy Flashing Light
1014 Iluminación para la boya
1014 Illumination Bouée d'ancre
1014 Illuminazione Grippiale



1.

PUSH the button before use



The light flashes automatically just in the dark.

2.

Battery Change



3.

Fix the light

